



# CAR-TOPPING YOUR KAYAK

The Venus line was designed specifically to help women get their kayaks to the water. Now you can load up and head to your favorite paddling destination without help.



Step 1 - Position hands on whichever grab handles are most comfortable for you.



Step 2 - Lift with your legs, resting kayak on your knees if needed.



Step 3 - Use the unique car-topping handle located toward the bow of the boat to guide the boat onto the top of the car.



Step 4 - Lift and guide kayak onto the car rack.



Step 5 - Let the car rack take the weight of the kayak.



Step 6 - Push kayak into position and securely tie the boat down to the kayak rack. Make sure the boat is secure before driving. Please contact your local dealer about appropriate racks and tie down procedures.



JOHNSON  
OUTDOORS

[www.oceankayak.com](http://www.oceankayak.com) • 800-8-KAYAKS